

Locking / Chamfers




- Twist the locking knob to lock the dog in place.



- With the chamfer fitted the parf dog will be flush if using a UJK top.

Creating a Chamfer



- If you are creating a top with a UJK parf guide system a small chamfer will be needed. Use either the UJK chamfer cutter or router.



- The parf super dog can also be inserted from beneath the work top to create a low profile dog.

Axminster Tools & Machinery Ltd
Weycroft Avenue, Axminster, Devon EX13 5PH

ujktechnology.co.uk

Leaflet Ref: 104397



Parf Super Dog

Made in UK



Code 104302

Overview



Configurations

The parf super dog can be assembled in three configurations.



Stop ring chamfer



Cap spacer for completely flush



25mm Mid bush register



Turn Over...